


ACUORN

LUSSO Quickstart Guide

Tubes type 300B, PX25, PX4, 45, 2A3 are for use with LUSSO.

Insert the tubes into the UX4 (U4A) socket or european tubes via the B4 (A4A) adapters.

Note: hold the stand, not the glass.




Select filament voltage tubes

300B set 5 Volt

PX25, PX4 set 4 Volt

2A3, 45 set 2.5 Volt

Note: after changing tubes, make sure the voltage is correct.




Connecting a pre-amplifier or integrated amplifier to LUSSO. RCA socket red right channel, white left channel.

Note: requires works with the device with volume control.

Output level depending on the amplification factor tubes:


300B...3,9 PX4...5,0 PX25...9,5 2A3...4,2 45...3,5



Select between the USB audio device and SPDIF inputs via toggle switches on the rear panel (can change inputs at any time).


Connect to a computer, notebook, tablet or music streamer using a USB audio cable.

Connect to a CD player or music streamer using an SPDIF cable.



Connecting the power to LUSSO. Supports 120-240 Vac network voltage. AC power plugs must be connected to the earth (ground).

Note: devices are switched off, connect mains IEC cable to the input.



Switch on the device, turn on pressing the power button on the rear panel.

Its start-up right orange led power on, then left orange led indicates DAC is on. Left side blue led indicates dsd signal processing.

Note: turning off the device power: first turn off the amplifier, then turn off the LUSSO.

